

# Nostalgic Warehouse Door Hardware Installation Instructions

## LONG PLATE PRE-ATTACHED KNOBS

## Single Cylinder Handleset

Note: Handlesets fit doors 1-3/4" to 2-1/4" thick.

**A**

**USE INCLUDED DOOR PREPARATION TEMPLATE FOR NON-PREPARED DOORS**

**USE INCLUDED PLASTIC TEMPLATE FOR PREPPED DOORS**

**B**

**Install Deadbolt and Handleset Latches**

**C**

**Latch Tongue Note**

Bevel side of latch tongue should contact curved end of face plate, and curved end of strike plate.

**D**

**Deadbolt Latch Tongue Note**

**E**

**Install Cylinder and Escutcheon**

**F**

**Insert Cylinder Assembly into Escutcheon, and place on door exterior. Attach deadbolt adaptor plate with provided screws.**

**G**

**Attach Thumbturn Assembly with provided screws.**

**H**

**Insert Handleset Spindle**

**I**

**Install Exterior Handleset on Door Exterior (part #16)**

**J**

**Install Long Plate with Knob on Door Inside**

**K**

**Install Jamb Strike Plate**

# Exploded Drawing Single Cylinder Handleset With Pre-Attached Knob

**Part  
Number**   **Part  
Description**

1. Deadbolt Latch
- 1A. Latch Tongue
2. 3/4" Latch & Strike Wood Screws (8)
3. Cylinder Assembly (W/Keys)
  - 3A. Cylinder Body
  - 3B. Tailpiece
  - 3C. Spin Ring
4. Escutcheon
5. Deadbolt Adapter Plate
6. 2-3/4" Machine Screws (2)
7. Thumbturn Assembly
8. 5/8" Thumbturn Machine Screws (2)
9. Dustbox for Deadbolt
10. Door Frame Reinforcer
11. 3" Reinforcer Wood Screws (2)
12. Strike Plate for Deadbolt
13. Handleset Latch
  - 13A. Latch Tongue
14. Latch Faceplate
15. Handleset Spindle
16. Handleset
17. Adapter Plate
18. Adapter Plate Screws (2)
19. Long Plate
20. 3/4" Plate Mounting Screws
21. Knob
22. Screw Cover Adapter
23. 2-7/8" Lower Mounting Screw
24. Mounting Screw Cover
25. Dustbox for Handleset
26. Strike Plate for Handleset

