

PARTS INCLUDED:

House Number	1 pc	1/2" Spacers	2 pcs
Template (On Box)	1 pc	3/4" Spacers	2 pcs
Mounting Bolts	2 pc		

TOOLS REQUIRED: Pencil, drill, 11/64 inch drill bit, caulk

INSTALLATION INSTRUCTIONS Note: Designed to be installed on wood applications. Consult a professional for other applications.

1. Determine the desired mounting location for your house number(s). Using the supplied template (printed on the product box), mark the locations of mounting bolts.
2. Use a 11/64 inch diameter drill bit and an appropriate drill to make holes at these marks. Drill each hole 11/2" deep for 1/2 spacer or 11/4" deep if using 3/4" spacer.
3. Thread mounting bolts into the back of house number and insert the desired spacers. Apply a small amount of clear adhesive caulk in each of the holes (previously drilled) and press the house number posts firmly into the holes. Note: Gently tapping with a rubber mallet may be necessary to fully seat the number.

CARE: Wipe with a soft, dry cloth. Household cleaners and abrasives may damage the finish.

