

**Product(s):** DHDU8005,  
DHDU8006, DHDU8007

**Rev:** 21Aug12



## INSTRUCTIONS FOR INSTALLATION

San Michele  
DHDU8005



### INCLUDED PARTS

- 1 Dummy Plate
- 2 Wood Screws
- 1 Rosette
- 1 Dummy Trim Insert
- 1 Dummy Trim Insert Key
- 1 Set Screw (Knob 12mm, Lever 6mm)
- 1 Allen Wrench
- 1 Lever

### INSTRUCTIONS

1. Mark the door with a short horizontal line at the height you wish to locate the dummy set. (The height of active sets is about 36 -39" from the floor.) Then mark the door with a vertical line (approx. 2" long) 2 3/8" - 2 3/4" from the edge of the door. The point at which the 2 lines intersect is the center location of where your set will be installed.
2. From the center point on the vertical line, place a short horizontal line 3/4" above the center point and another 3/4" below the center. These are your mounting screw locations.
3. Place dummy mounting plate on the door (V-groove on spindle facing down) and screw into place. (For easier installation, you can drill pilot holes in the screw locations prior to mounting the plate.)
4. Place rosette over the dummy plate so that the stud on the underside of the rosette aligns itself with the dummy plate cutout. This prevents the rosette from spinning.
5. Take the dummy trim insert and screw onto the threaded spindle to lock the rosette in place. Tighten further with dummy trim insert key to insure rigidity of spindle.
6. Slide knob or lever over spindle and tighten set screw with Allen wrench provided.
7. For full dummy installation, duplicate this procedure on the opposite site of the door.

### CARE

Clean only with a soft, dry cloth. To protect the finish, we do not recommend the use of polishes or abrasives. If you have any questions regarding your Vicenza Designs product, please contact your local dealer.



## DUMMY SET INSTALLATION (LEVER)

